

Ref No.	IC8001																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	3.0	3.0	0	3.0	3.2	3.4	3.0	3.1	0	3.1	3.1	3.3	2.9	3.0	2.8	0	3.0	3.0	3.4	0
STANDBY	3.0	3.0	0	3.1	3.2	3.3	3.1	3.1	0	3.2	3.1	3.3	0	3.1	0	0	3.1	3.0	3.3	0
Ref No.	IC8001																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
CD PLAY	0	3.3	2.7	1.7	2.2	1.2	2.5	3.4	0	2.3	0.9	2.3	2.4	3.4	0	2.5	2.0	2.2	1.7	2.4
STANDBY	0	3.3	2.9	0	2.4	1.2	2.6	3.3	0	2.7	0.4	2.6	2.3	3.3	0	2.7	1.8	2.6	1.3	2.3
Ref No.	IC8001																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
CD PLAY	2.3	2.6	0.7	1.2	1.8	1.5	2.3	3.4	0	2.3	0.8	2.3	3.3	0	0	2.8	3.3	0.7	3.3	3.3
STANDBY	2.4	2.6	0.4	1.2	2.1	0.8	2.6	3.3	0	2.3	0.9	2.6	3.3	0	3.3	2.8	3.3	0.6	3.3	3.3
Ref No.	IC8001																			
MODE	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
CD PLAY	0	3.3	0	0	0	0.5	0	3.0	2.8	3.1	0	1.6	3.1	0	1.7	1.6	1.7	0.1	3.3	0
STANDBY	0	3.3	0	0	0	0.7	0	3.0	0	3.0	0	3.3	3.1	0	1.7	0	0	3.3	0	3.3
Ref No.	IC8001																			
MODE	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
CD PLAY	3.3	0	3.3	3.4	0	0	0	0	1.2	0	0	0	0	0	0	0	0	3.3	3.3	0
STANDBY	3.3	0	0	3.3	0	0	0	0	0	0	0	0	0	0	0	0	0	3.3	0.8	0
Ref No.	IC8001																			
MODE	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120
CD PLAY	0	2.1	1.8	0.1	0	1.7	3.3	2.1	2.0	1.8	1.8	0.7	0.7	1.7	1.7	1.7	1.7	3.3	1.9	1.7
STANDBY	2.4	2.1	1.8	-0.1	0	1.7	3.3	2.1	2.1	1.8	1.8	0.7	0.7	1.7	1.6	1.6	1.6	3.3	1.9	1.7
Ref No.	IC8001																			
MODE	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140
CD PLAY	1.4	0	0	0.1	0	1.0	2.2	1.7	2.6	2.6	2.7	2.6	2.6	2.5	2.5	2.4	2.4	2.4	1.7	1.7
STANDBY	1.4	0	0	0	0	0	0	1.7	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	1.7	1.6
Ref No.	IC8001																			
MODE	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160
CD PLAY	3.4	1.2	1.8	2.2	0	1.7	1.7	1.7	0.4	3.3	0.5	0.4	1.0	1.0	2.3	0.4	0	0.8	3.4	0
STANDBY	3.3	1.2	1.9	2.1	0	1.7	1.7	1.7	0.4	3.3	0.5	0.4	1.0	1.0	2.2	0.4	0	0.8	3.3	0
Ref No.	IC8001																			
MODE	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	177	178	179	180
CD PLAY	3.4	0	1.6	0	1.5	1.5	3.4	0.2	1.7	1.6	1.3	1.2	0	0	0	1.3	1.7	3.4	0	3.3
STANDBY	3.3	0	1.6	0	1.5	1.5	3.3	0	1.7	1.6	0	1.2	0	0	0	0	1.7	3.3	0	3.3
Ref No.	IC8001																			
MODE	181	182	183	184	185	186	187	188	189	190	191	192	193	194	195	196	197	198	199	200
CD PLAY	0	3.3	0	0	0	0	0	0.1	0.1	3.4	0.1	1.0	1.6	0.7	1.4	3.4	-	-	-	-
STANDBY	0	3.3	0	0	0	0	0	0	0	3.3	0	0.6	0.3	0.3	3.3	3.3	0.3	0.6	0.6	0.6
Ref No.	IC8001																			
MODE	201	202	203	204	205	206	207	208	209	210	211	212	213	214	215	216	217	218	219	220
CD PLAY	0.1	3.4	-	-	0.1	-	-	-	3.4	-	-	-	0	2.8	2.8	3.4	2.0	0	1.2	1.5
STANDBY	0	3.3	0.6	0.6	0	0.6	0.6	3.3	3.3	0.6	0.6	0	0	2.9	3.3	3.3	2.2	0	1.2	1.6
Ref No.	IC8001																			
MODE	221	222	223	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239	240
CD PLAY	0.2	0	1.6	0.2	3.4	1.7	0.1	1.6	0	0	3.4	1.6	0.1	2.4	0	1.2	0	0.1	3.4	3.2
STANDBY	0	0	1.6	0	3.3	1.6	0	1.5	0	0	3.3	1.6	0.1	2.9	0	1.2	0	0	3.3	3.2
Ref No.	IC8001																			
MODE	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255	256				
CD PLAY	1.6	0	1.6	3.2	3.3	3.4	0	3.3	2.9	0	2.8	2.8	0	3.0	3.4	2.9				
STANDBY	1.6	0	1.6	3.2	3.3	3.3	0	3.3	2.9	0	2.9	2.9	0	3.1	3.3	3.0				
Ref No.	IC8051																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	3.4	3.0	3.4	3.0	3.1	0	3.0	3.1	3.4	3.0	2.9	0	2.8	3.4	2.8	3.3	3.3	3.2	3.2	2.4
STANDBY	3.3	3.1	3.3	3.1	3.1	0	3.1	3.2	3.3	3.0	3.0	0	2.9	3.3	2.9	3.3	3.3	3.2	3.2	2.6
Ref No.	IC8051																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
CD PLAY	1.6	0	0.1	0.2	0.2	2.0	3.3	0	1.5	1.6	1.7	1.6	0.1	0.1	0	0	3.4	1.6	2.8	0
STANDBY	1.7	0	0.1	0.2	0.2	2.2	3.3	0	1.6	1.6	1.7	1.5	0.1	0	0	0	3.3	1.6	2.9	0
Ref No.	IC8051																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54						
CD PLAY	0	3.0	3.3	3.0	3.0	0	3.0	3.1	3.3	2.9	2.8	0	2.9	0						
STANDBY	0	3.1	3.3	3.0	3.1	0	3.1	3.2	3.3	2.9	2.9	0	0	0						
Ref No.	IC8111																			
MODE	1	2	3	4	5	6	7	8												
CD PLAY	3.3	0	0	1.9	4.8	0	0	4.8												
STANDBY	3.3	0	0	1.9	4.9	0	0	4.9												
Ref No.	IC8251																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	1.7	1.7	1.7	1.7	1.7	1.7	0	4.8	3.3	0	2.8	2.8	2.8	2.8	2.1	2.1	2.1	2.0	0	0
STANDBY	1.7	1.7	1.7	1.7	1.7	1.7	0	4.9	0	0	2.8	2.8	2.8	2.8	2.1	2.1	2.1	2.1	0	0
Ref No.	IC8251																			
MODE	21	22	23	24	25	26	27	28												
CD PLAY	4.8	9.1	1.7	1.7	1.7	1.7	3.3	3.1												
STANDBY	4.9	9.2	1.7	1.7	1.7	1.7	0	3.1												
Ref No.	IC8271																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	0	7.6	0	7.6	0	0	7.6	0	2.8	2.8	2.8	2.8	2.8	2.8	0.9	0	0.7	0	2.4	0.1
STANDBY	0	0.3	0	0.3	0	0	0.3	0	4.9	4.9	4.9	4.9	4.9	4.9	0	0	0	0	4.9	4.8
Ref No.	IC8271																			
MODE	21	22	23	24	25	26	27	28												
CD PLAY	1.7	1.6	3.3	1.6	4.8	0	9.2	9.2												
STANDBY	1.7	1.7	0	3.3	4.9	0	9.3	9.3												
Ref No.	IC8451																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	3.3	3.3	0	0	0	0	0	0	2.4	2.5	2.4	2.5	2.4	2.5	2.5	2.5	0	5.0	0	2.5
STANDBY	0	0	0	0	0	0	0	0	2.4	2.5	2.4	2.5	2.4	2.5	2.5	2.5	0	5.0	0	2.4