

Ref No.	IC8451																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
CD PLAY	0	5.0	0	5.0	0	5.0	0	5.0	0	3.3	1.3	3.3	0.3	3.3	2.8	3.3	3.1	1.7	1.7	1.7
STANDBY	0	5.0	0	5.0	0	5.0	0	5.0	0	0	0	0	0.3	3.3	2.8	3.3	3.1	1.7	1.8	1.6
Ref No.	IC8451																			
MODE	41	42	43	44	45	46	47	48												
CD PLAY	1.7	0	3.3	0	1.3	0	0	3.3												
STANDBY	1.7	0	3.3	0	0	0	0	0												
Ref No.	IC8601																			
MODE	1	2	3																	
CD PLAY	0	3.1	3.4																	
STANDBY	0	3.1	3.3																	
Ref No.	IC8605																			
MODE	1	2	3	4	5															
CD PLAY	0.6	1.2	0	0	1.1															
STANDBY	0.6	1.2	0	0	1.1															
Ref No.	IC8611																			
MODE	1	2	3	4	5	6	7	8												
CD PLAY	0	0	0	0	3.3	3.3	0	3.3												
STANDBY	0	0	0	0	3.3	3.3	0	3.3												
Ref No.	IC8651																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	1.4	2.3	2.6	2.5	2.2	2.4	2.2	2.2	1.7	0	3.4	3.1	0	3.4	0.6	0.9	0.7	2.3	2.5	2.4
STANDBY	0.8	2.6	2.7	2.6	2.2	2.3	2.4	2.4	2.1	0	3.3	3.1	0	3.3	0.6	0.5	0.4	0	2.7	2.3
Ref No.	IC8651																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
CD PLAY	1.7	0.8	2.0	1.7	2.7	2.2	0	2.3	0.9	0.7	1.0	0.8	1.5	0.9	1.4	1.3	3.4	1.3	0.9	1.5
STANDBY	2.0	0.9	1.8	1.3	2.9	2.5	0	2.6	0.9	0.6	1.1	0.7	1.6	0.8	1.5	1.4	3.3	1.4	0.7	1.3
Ref No.	IC8651																			
MODE	41	42	43	44	45	46	47	48												
CD PLAY	1.4	1.4	1.8	1.6	1.9	0	3.4	2.2												
STANDBY	1.3	1.6	1.8	1.6	1.9	0	3.3	2.7												
Ref No.	IC8691																			
MODE	1	2	3	4	5															
CD PLAY	3.0	3.0	0	4.3	4.8															
STANDBY	3.0	3.0	0	4.4	4.9															
Ref No.	IC8695																			
MODE	1	2	3	4	5															
CD PLAY	2.8	2.8	0	4.0	4.8															
STANDBY	2.9	2.9	0	4.2	4.9															
Ref No.	Q8550																			
MODE	E	C	B		E	C	B		E	C	B		E	C	B		E	C	B	
CD PLAY	4.9	4.9	4.2		0	4.9	0.1		4.9	0	4.9		0	0.1	0.7		0.4	3.7	1.0	
STANDBY	5.0	4.9	4.3		0	4.9	0		4.9	0	4.9		0	0.1	0.7		0	4.9	0	
Ref No.	Q8562																			
MODE	E	C	B		E	C	B		E	C	B		E	C	B		E	C	B	
CD PLAY	4.3	2.2	3.7		0	0.1	0.6		0	3.1	0.1		0	2.8	0		3.4	3.3	0.1	
STANDBY	4.9	0	4.9		0	0.1	0.6		0	3.1	0.1		0	0	3.3		3.3	-0.3	3.3	
Ref No.	Q8551																			
MODE	E	C	B		E	C	B		E	C	B		E	C	B		E	C	B	
CD PLAY	4.9	4.9	4.2		0	4.9	0.1		4.9	0	4.9		0	0.1	0.7		0.4	3.7	1.0	
STANDBY	5.0	4.9	4.3		0	4.9	0		4.9	0	4.9		0	0.1	0.7		0	4.9	0	
Ref No.	Q8561																			
MODE	E	C	B		E	C	B		E	C	B		E	C	B		E	C	B	
CD PLAY	4.3	2.2	3.7		0	0.1	0.6		0	3.1	0.1		0	2.8	0		3.4	3.3	0.1	
STANDBY	4.9	0	4.9		0	0.1	0.6		0	3.1	0.1		0	0	3.3		3.3	-0.3	3.3	