


## A DVD MODULE(DV2) CIRCUIT

 : +B SIGNAL LINE   
  : CD-DA SIGNAL LINE   
  : DVD(VIDEO) SIGNAL LINE   
  : DVD(AUDIO) SIGNAL LINE






# SCHEMATIC DIAGRAM-3

## B MAIN CIRCUIT

— : +B SIGNAL LINE    ➡ : MAIN SIGNAL LINE    DVD : DVD(VIDEO) SIGNAL LINE    ➡ : FM/AM SIGNAL LINE

TO DVD MODULE CIRCUIT (FP8101) ON SCHEMATIC DIAGRAM-1



VAM SIGNAL LINE

