




OPTICAL PICK UP UNIT




SPINDLE MOTOR UNIT




IC8001  
MN2DS003APH  
DV2




IC8251  
C0GBG0000044  
TRACKING COIL/FOCUS COIL/TRVERSE MOTOR DRIVE




OPTICAL PICK UP UNIT






IC8611  
C3EBGZ000001  
EE PROM







TUNER PACK








SIGNAL LINES


 : MAIN SIGNAL LINE


 : FM SIGNAL LINE


 : FM OSC SIGNAL LINE


 : AM SIGNAL LINE

 : AM OSC SIGNAL LINE

 : FM /AM SIGNAL LINE

 : DVD AUDIO SIGNAL LINE

 : DVD VIDEO SIGNAL LINE

 : CD-DA (AUDIO /VIDEO) SIGNAL LINE

( ) Indicates the Pin No. of Right Channel.

NOTE : Signal Lines are applicable to the Left Channel only.

