




Item		FL Display	Key Operation
Mode Name	Description		Front Key
Doctor Mode	To enter into Doctor Mode		<p>1.In CD Mode: Press [■] button on main unit follow by [4] and [7] on remote control.</p> <p>2.To exit, press [OK] button on remote control or press [⦿/I] button on main unit or remote control.</p>
Micro-P Version Display	<p>To check the firmware version for Jupiter & Microprocessor IC.</p> <p>Display 1 will display for 2 secs, followed by display 2.</p>	<p>Display 1:</p>  <p>↓</p> <p>Display 2:</p> 	<p>In Doctor Mode:</p> <p>1.Press [2] button on remote control.</p>