

Ref No.	IC2701					IC2723					IC2741														
MODE	1	2	3	4	5	1	2	3	4	5	1	2	3	4	5										
CD PLAY	6.0	-4.7	-8.5	-3.1	6.0	-1.6	-5.0	2.1	-1.3	-1.2	-1.6	-5.0	2.1	-1.3	-1.2										
STANDBY	16.5	7.8	-2.2	0.9	11.0	5.8	-1.3	5.8	-0.4	3.3	5.8	-1.3	5.8	-0.4	3.3										
Ref No.	IC2761																								
MODE	1	2	3																						
CD PLAY	9.2	-8.0	4.3																						
STANDBY	11.9	-1.9	16.5																						
Ref No.	IC2801																								
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20					
CD PLAY	1.5	0	0	0	-0.6	-0.6	-0.6	-0.6	-0.6	0	1.0	0	-0.6	-0.6	-0.6	-0.6	-0.6	0.9	-0.6	-0.6					
STANDBY	1.6	1.6	1.6	1.6	1.6	1.6	0	-0.9	-0.9	1.0	0.6	-3.0	1.6	0.2	1.6	3.3	3.3	3.3	0	2.0					
Ref No.	IC2801																								
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40					
CD PLAY	-1.3	-0.5	0	0	-0.6	-134	-0.6	-0.4	-0.65	1.9	0	-1.5	0	0	1.9	-2.1	-1	0	-0.5	-0.2					
STANDBY	2.6	2.6	2.6	2.6	2.6	2.8	2.8	0	3.3	0	3.5	3.6	4.3	4.3	55.4	55.6	0.6	-0.6	4.1	3.2					
Ref No.	IC2801																								
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60					
CD PLAY	0	0	1	-0.8	1	-0.2	-0.9	-2	-0.9	-0.7	-0.2	0	2.6	0.7	-1.3	0.4	1.3	-0.5	-0.5	0					
STANDBY	3.9	3.8	1.6	0.5	3.6	-0.6	0	3.2	3.2	3.1	2.9	2.8	-0.5	2.6	2.5	2.1	-0.5	1.7	2.1	2					
Ref No.	IC2801																								
MODE	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80					
CD PLAY	2.6	1.2	-2.1	-0.6	-0.3	0	2.7	1.6	-1.8	-1	-0.5	-0.3	0	0.8	0.48	0.9	-0.5	0.4	0.8	-2.1					
STANDBY	2.2	3.3	1.6	0.5	1.5	1.6	6	6.1	6.2	0.6	1.9	6.3	0.6	2	2	2.1	2.1	2.1	2.6	0.6					
Ref No.	IC2801																								
MODE	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100					
CD PLAY	1.8	-1.8	-0.4	0	2.2	-1.5	-0.8	-0.5	2.4	0	-1.2	1.6	1	0.3	0	-2.6	1.6	0.7	0.4	0.3					
STANDBY	2.2	2.2	2.2	2.2	3.3	0.5	2.2	2.2	3	2.5	2.2	3.3	3.3	2.95	2.5	0.5	2.5	3.3	3.3	3.3					
Ref No.	IC2803																								
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20					
CD PLAY	-0.6	0	-0.7	0.6	0.4	0.2	0	0.2	0	0	0	0	0	0	0	0	0	-0.7	0	0					
STANDBY	-0.8	0.5	0.4	0.4	0.4	0.4	0.4	0.2	0.2	-0.2	-0.2	0.7	0.5	0.4	0.4	0.4	0.4	0	0	0					
Ref No.	IC2803																								
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40					
CD PLAY	4.1	-1.4	-0.7	-0.2	-3.0	-0.6	1.2	0.7	0.4	0.3	0	0	0	0	0	0	0	0	-0.5	0					
STANDBY	0	0.4	0.4	0.4	0.3	0	0.4	0	0	0	0	0	-0.3	0.3	0.3	0.3	0.3	0.3	-0.8	0.3					
Ref No.	IC2803																								
MODE	41	42	43	44	45	46	47	48	49	50	51	52													
CD PLAY	-0.5	0	-0.5	0	0	0	0	-0.5	-0.4	0.2	-0.4	0													
STANDBY	-0.6	0.2	0.6	0.2	0.5	0.2	0.2	-0.6	0	-0.4	0.3	0.2													
Ref No.	IC2804																								
MODE	1	2	3	4	5	6	7	8				1	2	3	4	5	6	7	8						
CD PLAY	-6	0	0	-8.1	3.1	1.1	0.2	7.9				-0.7	-0.6	-2.3	-1.4	0.5	0.3	-1.1	2.3						
STANDBY	-4.4	-0.8	-0.8	-9.1	-0.9	-0.6	-4.2	9.3				-0.7	3.3	3.9	3.8	1.6	1.6	0.5	3.2						
Ref No.	IC2901																								
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16									
CD PLAY	0	1	1.6	1.6	3.2	4.1	1.6	1.6	4.2	4.1	4.3	3.2	1.5	1.6	4.1	3.2									
STANDBY	0	1	1.6	1.6	3.3	1.9	1.6	1.6	1.9	1.9	1.9	3.3	1.6	1.6	1.9	3.3									
Ref No.	Q2011					Q2012					Q2311					Q2312					Q2317				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	3.3	11.7	3			3.3	11.7	3			-0.8	-0.8	0.6			-0.8	-0.8	0.6							
STANDBY	3.4	11.9	3.2			3.4	11.9	3.3			-0.8	-0.8	0.59			-0.8	-0.8	0.6							
Ref No.	Q2359					Q2360					Q2371					Q2372					Q2373				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	-2.6	-2.6	0.6			-2.6	-2.6	0.6			1.3	3.3	-0.3			-2.6	-2.6	0.6							
STANDBY	-2.6	-2.6	0.6			-2.6	-2.6	0.6			-0.1	3.3	0			-2.6	-2.6	0.6							
Ref No.	Q2374					Q2375					Q2417					Q2501					Q2521				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	11.9	11.5	11.8			-2.6	-2.6	0.6			-9.2	-11.6	11.8			1.3	3.3	-0.3							
STANDBY	11.9	3.1	11.9			-2.6	-2.6	0.6			-9.2	-11.4	-9.8			-0.1	3.3	0							
Ref No.	Q2522					Q2523					Q2524					Q2708					Q2711				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	11.9	11.5	11.8			-2.6	-2.6	0.6			-9.2	-11.6	11.8			-2.6	-2.6	0.6							
STANDBY	11.9	3.1	11.9			-2.6	-2.6	0.6			-9.2	-11.4	-9.8			-2.6	-2.6	0.6							
Ref No.	Q2735					Q2743					Q2745					Q2751					Q2761				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	8.0	10.0	8.4			-1	-8.0	-0.6			3.3	0	-0.9			9.44	16.7	10.0							
STANDBY	8.0	11.2	8.6			-1.9	-9.8	-0.6			-1.5	0	3.3			9.4	16.5	10.0							
Ref No.	Q2771					Q2772					Q2800					Q2812					Q2900				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	-2.3	3.1	-18.4			0	3.1	-2.4			-2.6	-2.6	0.6			1.3	3.3	-0.3							
STANDBY	-2.4	3.1	-18.4			0	3.1	-2.4			-2.6	-2.6	0.6			-0.1	3.3	0							
Ref No.	Q2942					Q2943					Q2947					Q2948					Q2949				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	-2.6	-2.6	0.6			11.9	11.5	11.8			-9.2	-11.6	11.8			1.3	3.3	-0.3							
STANDBY	-2.6	-2.6	0.6			11.9	3.1	11.9			-9.2	-11.4	-9.8			-0.1	3.3	0							
Ref No.	Q2961					Q2962					Q2967					Q2970					Q3400				
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	-2.6	-2.6	0.6			11.9	11.5	11.8			0.9	11.7	2			3.3	-0.4	3							
STANDBY	-2.6	-2.6	0.6			11.9	3.1	11.9			0.9	11.9	2			3.3	-0.4	3.0							
Ref No.	Q3401					Q3450					QR111					QR2317									
MODE	E	C	B			E	C	B			E	C	B			E	C	B							
CD PLAY	-2.6	-2.6	0.6			8.0	10.0	8.4			-2.6	-2.6	0.6			-1.1	-7.5	3.3							
STANDBY	-2.6	-2.6	0.6			8.0	11.2	8.6			-2.6	-2.6	0.6			1.7	1.7	-0.9							