

| Ref No. MODE | IC6901 | | | | | | | | | | | | | | | | | | | |
|-----------------|--------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| CD PLAY | -0.1 | -0.1 | -15.4 | -21.5 | -21.4 | -21.4 | -14.4 | -21.4 | -12.1 | -16.8 | -12.1 | -21.5 | 0 | 0 | -23.8 | -21.5 | -23.8 | -21.4 | -19.1 | -23.8 |
| STANDBY | 0 | 0 | -14.5 | -21.5 | -23.8 | -19.2 | -16.8 | -9.8 | -14.5 | -14.5 | -14.5 | -12.2 | 0 | 0 | -23.8 | -21.5 | -21.5 | -14.5 | -21.5 | -23.8 |
| Ref No. MODE | IC6901 | | | | | | | | | | | | | | | | | | | |
| | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |
| CD PLAY | -26.5 | -26.4 | -26.4 | -26.5 | 0 | 0 | -26.4 | -26.4 | -26.4 | -26.5 | -26.5 | -26.5 | -26.5 | -26.5 | -26.4 | -26.4 | 0 | 0 | -29.1 | 0 |
| STANDBY | -26.5 | -26.5 | -26.5 | -26.5 | 0 | 0 | -26.5 | -26.5 | -26.5 | -26.5 | -26.5 | -26.5 | -26.5 | -26.6 | -26.5 | -26.5 | 0 | 0 | -29.2 | 0 |
| Ref No. MODE | IC6901 | | | | | | | | | | | | | | | | | | | |
| | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | | | | | | | | | | | | |
| CD PLAY | 4.6 | 2.1 | 3.3 | 0.6 | 0 | 2.0 | 1.9 | 4.3 | | | | | | | | | | | | |
| STANDBY | 4.6 | 1.9 | 3.2 | 0.9 | 0 | 2.0 | 1.9 | 4.3 | | | | | | | | | | | | |

| Ref No. MODE | Q6900 | | | | Q6901 | | | | Q6902 | | | | Q6903 | | | | Q6904 | | | |
|-----------------|-------|-----|-----|--|-------|-----|---|--|-------|-----|---|--|-------|-----|---|--|-------|-----|---|--|
| | E | C | B | | E | C | B | | E | C | B | | E | C | B | | E | C | B | |
| CD PLAY | 0 | 0.1 | 4.6 | | 0 | 7.8 | 0 | | 0 | 7.8 | 0 | | 0 | 7.8 | 0 | | 0 | 7.9 | 0 | |
| STANDBY | 0 | 0.1 | 4.6 | | 0 | 7.8 | 0 | | 0 | 7.8 | 0 | | 0 | 7.8 | 0 | | 0 | 7.9 | 0 | |